

列表

序号	物料代码	物料名称	英文名 English	数量
1	100010117	O型密封圈(φ11.2×2.65 氟橡胶)	O-Ring, φ11.2×2.65	2
2	100011270-0002	GB5789螺栓M6×30(兰白锌)	Bolt, M6×30	11
3	100023657	2V78FE/P机油精滤器座	Secondary Oil Filter	1
4	100004048	1P90F精滤器连接螺管	Connection Pipe	1
5	100053326	2V78FE/P板簧卡箍(φ15.5×12 50CrV4)	Clamp	4
6	100011220-0001	GB5787螺栓M6×25(兰白锌)	Bolt, M6×25	2
7	100053380	2V78FE/P机油冷凝器护板	Governor Gear Bracket	1
8	100055278	2V78FE/P机油冷凝器总成	Oil Radiator	1
9	100004081	2V78FE/P机油冷凝器安装支架	Oil Radiator Bracket	1
10	100011261-0004	GB5789螺栓M6×12(兰白锌)	Bolt, M6×12	15
11	100000655	线卡B	Clip	4
12	100009378	168FA火花塞(F6RTC)	Spark Plug	2
13	100004087-0001	1P90F机油精滤器(6902色)	Oil Filter	1
14	100000568-0002	扎带(长150mm 黑色)	Tape, L=150mm	1
15	100053642	平垫圈(φ10.5×2×φ18 铜)	Washer, φ10.5×2×φ18	2
16	100053223	2V78FE/P油管接头(长45mm)	Fuel Tube Joint	2
17	100053224	编织油管(φ9.5×φ17.5×330)	Fuel Hose, φ9.5×φ17.5×330	2
18	100002442	2V78FE/P缸头导风罩二	Cylinder Head Baffle	1
19	100010278	2V78FE/P放油螺栓(M14×1.5×15)	Earth Bolt	2
20	100010474	平垫圈(φ14×1.5×φ22)	Washer, φ14×1.5×φ22	2
21	100002765	2V78FE/P曲轴箱体(呼吸阀隔板)	Crankcase	1
22	100011463-0002	GB6177.1螺母M6(兰白锌) 平板	Nut, M6	2
23	100009355	2V78FE/P点火器组合(火花帽 152型 两极靴 右)	Ignition Module	1
24	100003947	2V78FE/P曲轴总成(O4型)	Crankshaft	1
25	100010038	2V78FE/P机油传感器	Oil Sensor	1
26	100011264-0003	GB5789螺栓M6×16(兰白锌)	Bolt, M6×16	6
27	100010838-0001	GB70.1螺栓M6×16(兰白锌) 10.9级	Bolt, M6×16	2
28	100004013	2V78FE/P机油泵总成	Oil Pump	1
29	100004032	2V78FE/P油泵弹簧(高22mm)	Oil Pump Spring	1
30	100010937	GB308钢球φ9.5	Steel Ball, φ9.5	1
31	100010166	2V78FE/P曲轴箱密封垫	Gasket, Crankcase	1
32	100004067	2V78FE/P机油粗滤器组合	Breather Filter Screen	1
33	100003038	2V78FE/P左曲轴箱盖	Crankcase Cover	1
34	100067693	XP680A吊耳(缸头 65Mn 厚2.5)	Lift Hook	2
35	100011331-0002	GB5789螺栓M8×50(兰白锌)	Bolt, M8×50	9
36	100062435-0002	2V78FE/P机油尺组合(柱塞式 长 2913色)	Dipstick	1
37	100017626	油封(φ38×φ58×8 氟橡胶)	Oil Seal, φ38×φ58×8	2
38	100010118	O型密封圈(φ13.2×2.65 氟橡胶)	O-Ring, φ13.2×2.65	1
39	100010549	定位销φ8×12	Pin, φ8×12	3
40	100010531	平垫圈(φ38.5×1×φ54)	Washer, φ38.5×1×φ54	1
41	100008308	2V78FE/P调速从动齿组合	Governor Gear	1
42	100010525	平垫圈(φ17.4×1×φ25.9)	Washer, φ17.4×1×φ25.9	1
43	100004327	2V78FE/P凸轮轴部件	Camshaft	1
44	100010709	轴承(6003-Z)	Bearing, 6003	1
45	100011268-0003	GB5789螺栓M6×25(兰白锌)	Bolt, M6×25	5
46	100004500	2V78FE/P下摇臂组合	Lower Rocker Arm	1
47	100002459	缸头盖螺栓(M6×22)	Bolt, M6×22	8
48	100004589	173F排气门调节帽	Valve Adjust Cap, Exhaust	4
49	100004575	173F气门弹簧承座	Valve Spring Seat	2
50	100004576	182F气门锁夹	Valve Locker	8
51	100004573	2V78FE/P-A气门弹簧(钢丝直径φ2.7)	Valve Spring	4
52	100004516	182F气门弹簧座(锁夹式)	Valve Spring Seat	4
53	100004555	182F排气门(锁夹式)	Exhaust Valve	2
54	100004532	182F进气门(锁夹式)	Intake Vavle	2
55	100051984	2V78FE/P缸头螺栓(M10×1.25×87)	Bolt, M10×1.25×87	8
56	100051968	2V78FE/P缸头(右 锁夹式 燃烧室容积32.5)	Cylinder Head	1
57	100010562	定位销φ12×20	Pin, φ12×20	4
58	100004405	2V78FE/P推杆	Push Rod	4
59	100003271	2V78FE/P活塞环总成(减薄)	Piston Ring Set	2
60	100003109	2V78FE/P活塞(平顶)	Piston	2
61	100003221	168FA活塞销挡圈	Circlip	4
62	100003461	2V78FE/P连杆三组件	Connecting Rod Assembly	2
63	100004176-0002	2V78FE/P机油塞组合(2913色)	Oil Plug	1
64	100002334	2VP78FE/P缸头盖(带螺纹孔)	Valve Cover	1
65	100010188	2V78FE/P缸头盖密封垫(纸垫)	Gasket, Valve Cover	2
66	100009148	2VP78FE/P汽油泵衬套支架	Bush Bracket	1
67	100004602	173F挡油罩组合	Intake Valve Seal	2
68	100004427	190F摇臂组合(摇臂 螺栓 螺母)	Rocker Arm Assembly	4
69	100004474	173F摇臂座(改进型)	Rocker Arm Base	2
70	100007110	2V78FE/P缸头导风板	Shroud	2
71	100051970	2V78FE/P缸头密封垫(石墨)	Gasket, Cylinder Head	2
72	100003133	2V78FE/P活塞销	Piston Pin	2
73	100007989	173F油门调速柄开口销	Cotter Pin	2
74	100010456	平垫圈(φ8.5×2×φ15.8)	Washer, φ8.5×2×φ15.8	3
75	100017631	油封(φ8×φ14×4 丙烯酸脂)	Oil Seal, φ8×φ14×4	1

76	100010783	轴承(HK081210 滚针)	Bearing, HK081210	2
77	100010387	168FA缸头排气口双头螺栓(M8×34)	Stud, M8×34	4
78	100007985	2V78FE/P油门调速柄	Governor Gear Shaft	1
79	100011283-0002	GB5789螺栓M6×90(兰白锌)	Bolt, M6×90	4
80	100051027	2VP78FE/P空滤器总成(侧抽)	Air Filter Assembly	1
81	100004962	2VP78FE/P空滤器连接管	Air Filter Tube	1
82	100056216	2V78FE/P化油器总成(双腔_常闭_侧抽空滤器_60	Carburetor	1
83	100005943	2V78FE/P-A化油器垫	Gasket, Carburetor	3
84	100008454	2V78FE/P阻风门拉杆锁夹	Choke Linkage Lock Clamp	1
85	100008050	2V78FE/P-A阻风门拉杆	Choke Lever	1
86	100056674	GB680侧抽空滤器缓冲磨损胶套	Buffer Wear Jacket	2
87	100002878	2V78FE/P废气管(带卡箍)	Breather Hose	1
88	100011278-0001	GB5789螺栓M6×65(兰白锌)	Bolt, M6×65	1
89	100010331	2VP78FE/P双头螺栓	Stud	2
90	100004618	2V78FE/P-A进气弯管	Intake Manifold	1
91	100062814	2V78FE/P-A化油器隔热板(尼龙_厚3)	Insulator	1
92	100005640	2V78FE/P化油器进气管垫	Gasket, Intake Manifold	2
93	100005636	2V78FE/P-A化油器进气管	Intake Manifold	1
94	100010853-0001	GB70.1螺栓M8×50(兰白锌) 10.9级	Bolt, M8×50	4
95	100007904	2V78FE/P油门大拉簧二(长38 圈数16.75 刚度0.3	Governor Spring	1
96	100007905	2V78FE/P油门大拉簧一(长72 圈数24.25 刚度1.1	Governor Spring	1
97	100006092	2V78FE/P阻风门复位弹簧	Choke Spring	1
98	100008185	2V78FE/P油门操纵组合(远程操控_可回位)	Governor Gear Bracket Assembly	1
99	100007963	2V78FE/P-A油门操纵杆	Throttle Linkage	1
100	100008437	2V78FE/P油门支架组合	Governor Lever	1
101	100007933	2V78FE/P-A油门小拉簧	Idle Spring	1

102	100002333	2VP78FE/P缸头盖(无螺纹孔)	Valve Cover	1
103	100011568-0001	GB16674.1小盘螺栓M8×16(兰白锌)	Bolt, M8×16	7
104	100011550-0003	GB16674小盘螺栓M8×20(兰白锌)	Bolt, M8×20	3
105	100051969	2V78FE/P缸头(左 锁夹式 燃烧室容积32.5)	Cylinder Head	1
106	100006434	2V78FE/P排气消声器	Muffler	1
107	100011453-0003	GB6177.1螺母M8(兰白锌)	Nut, M8	4
108	100006943	2V78FE/P排气口密封垫	Gasket, Muffler	2
109	100009356	2V78FE/P点火器组合(火花帽 152型 两极靴 左)	Ignition Module	1
110	100002441	2V78FE/P缸头导风罩一	Cylinder Head Baffle	1
111	100011343-0002	GB5789螺栓M8×110(兰白锌)	Bolt, M8×110	2
112	100010556	定位销φ10×12	Pin,φ10×12	2
113	100009806	2V78FE/P电启动组件(直流电机 12V 状态C04)	Electric Starter	1
114	100011451-0003	GB6177.1螺母M5(兰白锌)	Nut, M5	2
115	100010044	2V78FE/P一体化整流分线器	Integrated Rectifier Device	1
116	100004064	2V78FE/P呼吸槽密封垫	Gasket, Breather Cover	2
117	100002570	2V78FE/P呼吸阀滤网	Breather Filter Screen	1
118	100004070	2V78FE/P呼吸阀隔板	Breather Cover	1
119	100004061	2V78FE/P呼吸槽盖板(呼吸阀隔板)	Breather Cover	1
120	100011222-0001	GB5787螺栓M6×30(兰白锌)	Bolt, M6×30	1
121	100009468	2V78FE/P压线板	Wire Board	1
122	100011224-0002	GB5787螺栓M6×35(兰白锌)	Bolt, M6×35	1
123	100011217-0002	小盘螺栓M6×16(兰白锌)	Bolt, M6×16	2
124	100062957	XP680A双头螺栓(M6×122 开挡69.5)	Stud, M6×122	2
125	100009452	2V78FE/P充电线圈(整流12V40W 60HZ 端口A1)	Charging Coil	1
126	100009016	QF10.0-E燃油过滤器	Fuel Filter	1
127	100009152	2V78FE/P-A进油管护套	Fuel Hose Jacket	1
128	100073231	2V78FE/P油管(汽油泵负压管 带护套)	Fuel Hose	1
129	100009150	2VP78FE/P进油管衬套	Fuel Hose Jacket	1
130	100031911-0004	GB5783螺栓M6×10(兰白锌)	Bolt, M6×10	1
131	100057408	GB680油管(汽油泵出油管 带EPA认证标识)	Fuel Hose	1
132	100057409	GB680油管(汽油泵进油管 带EPA认证标识)	Fuel Hose	1
133	100006107	2VP78FE/P汽油泵支架(螺栓压紧密封汽油泵)	Fuel Pump Bracket	1
134	100004221	衬套(φ6.5×φ10×24)	Bush, φ6.5×φ10×24	2
135	100006102	2V78FE/P汽油泵(螺栓压紧密封)	Fuel Pump	1
136	100011273-0003	GB5789螺栓M6×40(兰白锌)	Bolt, M6×40	2
137	100021845	GQ7.5/14.5喷头胶套	Spray Head Washer	2
138	100005966	2VP78FE/P挡风板	Choke Plate	1
139	100011004-0001	GB845自攻螺钉ST4.2×25(黑锌)	Self-tappling Screw, ST4.2×25	2
140	100010334	2VP78FE/P台阶螺栓	Bolt	2
141	100007130	2V78FE/P箱体左侧护罩	Shroud, Left	1
142	100062958	XP680A双头螺栓(M6×112.5 开挡61.5)	Stud, M6×112.5	2
143	100009589	2V78FE/P 飞轮组合(键槽夹角27.5度 锥度1:5)	Flywheel	1
144	100007041	2VP78FE/P叶轮	Cooling Fan	1
145	100007717	2V78FE/P叶轮压板	Cooling Fan Plate	1
146	100010494	平垫圈(φ20.5×5×φ40)	Washer, φ20.5×5×φ40	1
147	100011461-0001	GB6177.1螺母M20×1.5(兰白锌)	Nut, M20×1.5	1
148	100011260-0005	GB5789螺栓M6×10(兰白锌)	Bolt, M6×10	5
149	100007131	2V78FE/P箱体右侧护罩	Shroud, Right	1
150	100007658	2VP78FE/P导风外罩	Blower Housing	1
151	100064522	XP680A挡草罩(带衬套)	Shroud	1
152	100008477-0001	TC160盖型带盘螺母(M6 黑铬)	Nut, M6	4
153	100005159	QF2.5-ⅢED板簧卡箍(φ10.5×8)	Clamp	3
154	100005148	178-LU油管板簧卡箍(φ8)	Clamp	1

GB680(1TZZQQ073)
Part Illustrations

