

This diagram illustrates the exploded view of a tracked vehicle, showing the engine, transmission, drive shaft, sprockets, tracks, and various structural components. The parts are numbered 1 through 57, corresponding to the parts list table on the right.

4	ZY2310017	铲斗	1	32	ZY2310031	履带油缸小胶圈轴
5	ZY2310018A	左斗臂	1	33	ZY2310025	斗臂-销斗臂轴
6	ZY2310007	垫板	2	34	ZY2310008	液压油管
7	ZY2310053	履带油缸小胶圈轴	2	35	ZY2310008	大液压油缸
8	ZY2310001	履带油缸	1	36	ZY2310023	减振块
9	ZY2310048	板	8	37		限位开关
10	ZY2310006	左支架	1	38	ZY2310013	400L油桶轴
11	ZY2310003	新钢板	2	39		400L油桶
12	ZY2310004A	板	2	40	ZY2310012	压板轴
13		油门拉线	1	41	ZY2310011	压板弹簧
14	ZY2310050	叉手销杆	2	42	ZY2310010	减震轴
15	ZY2310048	叉手销杆	8	43	ZY2310002	减震轴
16	ZY2310049	手销轴	4	44	ZY2310001	大螺栓
17		衬套	1	45	ZY2310001	左限位板
18		高低速开关	1	46	180409438	履带
19		液压油管接头	1	47	ZY2310000	限位轴
20		主销	2	48	18047-200	尼龙绳
21	ZY2310035B	操作台	1	49	ZY2310045	护罩
22	ZY2310007B	扶手	1	50	ZY2310008	履带轴
23		履带轴	1	51	ZY2310028	垫板
24	ZY2310004	履带轴减震块	4	52	ZY2310020	排板
25	ZY2310014	履带轴	1	53	ZY2310018	限位杆
26		限位杆	1	54	ZY2310019	限位板
27	ZY2310037	底座	1	55	ZY2310028	限位板
28		限位板	1	56	ZY2310044	尼龙绳
				57	ZY2310005	尼龙绳

自动化设备厂